

Mounting Accessories

- For Ø25 mm (1") and Ø30 mm (1 3/16") with Straight Feet

3

	Fixing method	For door thickness	Item No.
In pairs on glass doors Door drilling Ø16 (5/8")		8-12 (5/16"-1/2")	909.03.900
One sided on glass doors (visible) Door drilling Ø16 (5/8")		8-12 (5/16"-1/2")	909.03.902
In pairs on wooden doors Door drilling Ø12.5 (1/2")		33-37 (1 5/16"-1 7/16")	909.03.869
		38-42 (1 1/2"-1 5/8")	909.03.870
		43-47 (1 11/16"-1 7/8")	909.03.871
		48-52 (1 7/8"-2 1/16")	909.03.872
		53-57 (2 1/16"-2 1/4")	909.03.873
		58-62 (2 5/16"-2 7/16")	909.03.874
One sided on wooden doors (visible) Door drilling Ø12.5 (1/2")		63-67 (2 1/2"-2 5/8")	909.03.875
		35-40 (1 3/8"-1 9/16")	909.03.879
		40-44 (1 9/16"-1 3/4")	909.03.880
		45-49 (1 3/4"-1 15/16")	909.03.881
		50-54 (1 15/16"-2 1/8")	909.03.882
		55-59 (2 3/16"-2 5/16")	909.03.883
One sided on wooden doors (concealed) With Rampa sleeve Door drilling Ø13.5 (9/16")			909.03.910
			909.03.910
One sided on wooden doors (concealed) With wood to metal dowel		40-62 (1 9/16"-2 7/16")	909.03.920
		from 62 (2 7/16")	909.03.930
One sided on plastic and metal doors (concealed) With self-cutting thread door drilling Ø10 (3/8") thread Ø11.8 (7/16")			909.04.800

Note
Each pull requires 2 mounting sets

Dimensions in mm
Inches are approximate

Dimensional data not binding. We reserve the right to alter specifications without notice.